



# FRONT SOFTRIDE® LEAF SPRINGS

**Softride® Technology** gives you all the vigorous off-road handling needed while providing the smooth street riding characteristics that you demand. Skyjacker's advanced method of shotpeening, tapered, leaves, Teflon® wear pads and 'presetting' process achieves articulation at its best...without sacrificing the life of the spring.

From this chart, you can find a 'Pair of Springs with Bushings' or 'Single Springs' and the 'Bushing Sets' needed for the Single unit (Ordered Separately). Also available are '**Fitted Leafs**'. Fitted Leafs are designed as an option Exclusively for Skyjacker® Softride® Lifted Leaf Springs. These are used when the additional weight of aftermarket accessories are installed such as a heavy winch bumper, an engine conversion, a swing-away tire carrier, all your extra gear, etc.).

FRONT LIFT	NOTES	Spring PAIRS WITH Bushings	Qty.	Bushing SETS For Spring PAIRS	SINGLE Spring	Qty.	Bushing SETS To Fit 2 Single Springs	Qty.	FITTED LEAFS For Pair
<b>CHEVROLET/GMC</b>									
<b>73-87 1/2 &amp; 3/4 Ton Pickup 4WD</b>									
2.5"		C125	1	Poly Included	C125S	2	SE11C	1	FLC125
4"		C140	1	Poly Included	C140S	2	SE11C	1	FLC140
6"		C160	1	Poly Included	C160S	2	SE11C	1	FLC160
8"		C180	1	Poly Included	C180S	2	SE11C	1	FLC180
<b>67-72 1/2 &amp; 3/4 Ton Pickup 4WD</b>									
2.5"		C225	1	Poly Included	C225S	2	SE11C	1	FLC225
4"		C240	1	Poly Included	C240S	2	SE11C	1	FLC240
6"		C260	1	Poly Included	C260S	2	SE11C	1	FLC260
8"		C280	1	Poly Included	C280S	2	SE11C	1	FLC280
<b>77-87 1 Ton Pickup</b>									
2.5"		C125	1	Poly Included	C125S	2	SE11C	1	FLC125
4"		C140	1	Poly Included	C140S	2	SE11C	1	FLC140
6"		C160	1	Poly Included	C160S	2	SE11C	1	FLC160
8"		C180	1	Poly Included	C180S	2	SE11C	1	FLC180
<b>88-91 Blazer, Jimmy - Full-Size</b>									
2.5"		C125	1	Poly Included	C125S	2	SE17C	1	FLC125
4"		C140	1	Poly Included	C140S	2	SE17C	1	FLC140
6"		C160	1	Poly Included	C160S	2	SE17C	1	FLC160
8"		C180	1	Poly Included	C180S	2	SE17C	1	FLC180
<b>73-87 Blazer, Jimmy - Full-Size</b>									
2.5"		C125	1	Poly Included	C125S	2	SE11C	1	FLC125
4"		C140	1	Poly Included	C140S	2	SE11C	1	FLC140
6"		C160	1	Poly Included	C160S	2	SE11C	1	FLC160
8"		C180	1	Poly Included	C180S	2	SE11C	1	FLC180
<b>67-72 Blazer, Jimmy - Full-Size</b>									
2.5"		C225	1	Poly Included	C225S	2	SE11C	1	FLC225
4"		C240	1	Poly Included	C240S	2	SE11C	1	FLC240
6"		C260	1	Poly Included	C260S	2	SE11C	1	FLC260
8"		C280	1	Poly Included	C280S	2	SE11C	1	FLC280
<b>88-91 Suburban 1/2 &amp; 3/4 Ton 4WD</b>									
2.5"		C125	1	Poly Included	C125S	2	SE17C	1	FLC125
4"		C140	1	Poly Included	C140S	2	SE17C	1	FLC140
6"		C160	1	Poly Included	C160S	2	SE17C	1	FLC160
8"		C180	1	Poly Included	C180S	2	SE17C	1	FLC180
<b>73-87 Suburban 1/2 &amp; 3/4 Ton 4WD</b>									
2.5"		C125	1	Poly Included	C125S	2	SE11C	1	FLC125
4"		C140	1	Poly Included	C140S	2	SE11C	1	FLC140
6"		C160	1	Poly Included	C160S	2	SE11C	1	FLC160
8"		C180	1	Poly Included	C180S	2	SE11C	1	FLC180
<b>67-72 Suburban 1/2 &amp; 3/4 Ton 4WD</b>									
2.5"		C225	1	Poly Included	C225S	2	SE11C	1	FLC225
4"		C240	1	Poly Included	C240S	2	SE11C	1	FLC240
6"		C260	1	Poly Included	C260S	2	SE11C	1	FLC260
8"		C280	1	Poly Included	C280S	2	SE11C	1	FLC280
<b>DODGE</b>									
<b>61-93 1/2 &amp; 3/4 Ton Pickup 4WD</b>									
2.5"		D200	1	Poly Included	D200S	2	SE12D	1	FLD200
4"		D400	1	Poly Included	D400S	2	SE12D	1	FLD400

# FRONT SOFTRIDE® LEAF SPRINGS

FRONT LIFT	NOTES	Spring PAIRS WITH Bushings	Qty.	Bushing SETS For Spring PAIRS	SINGLE Spring	Qty.	Bushing SETS To Fit 2 Single Springs	Qty.	FITTED LEAFS For Pair
<b>DODGE - Continued</b>									
<b>61-93 1/2 &amp; 3/4 Ton Pickup 4WD</b>									
6"		D600	1	Poly Included	D600S	2	SE12D	1	FLD600
8"		D800	1	Poly Included	D800S	2	SE12D	1	FLD800
<b>87-93 3/4 &amp; 1 Ton Pickup 4WD with Diesel Engine</b>									
1"		D100C	1	Poly Included	D100CS	2	SE12D	1	FLD100C
2"		D200C	1	Poly Included	D200CS	2	SE12D	1	FLD200C
4"		D400C	1	Poly Included	D400CS	2	SE12D	1	FLD400C
6"		D600C	1	Poly Included	D600CS	2	SE12D	1	FLD600C
<b>74.5-93 1 Ton Pickup 4WD with Gas Engine</b>									
1.5-2"		D200	1	Poly Included	D200S	2	SE12D	1	FLD200
3-4"		D400	1	Poly Included	D400S	2	SE12D	1	FLD400
5-6"		D600	1	Poly Included	D600S	2	SE12D	1	FLD600
7-8"		D800	1	Poly Included	D800S	2	SE12D	1	FLD800
<b>72-93 Ramcharger, Trailduster 4WD</b>									
2.5"		D200	1	Poly Included	D200S	2	SE12D	1	FLD200
4"		D400	1	Poly Included	D400S	2	SE12D	1	FLD400
6"		D600	1	Poly Included	D600S	2	SE12D	1	FLD600
8"		D800	1	Poly Included	D800S	2	SE12D	1	FLD800
<b>FORD</b>									
<b>00-04 Excursion 4WD with Gas Engine</b>									
4"		F920	1	Poly Included	F920S	2	SE90F		
6"		F940	1	Poly Included	F940S	2	SE90F		
8"		F960	1	Poly Included	F960S	2	SE90F		
<b>00-04 Excursion 4WD with Diesel Engine</b>									
6"		F945	1	Poly Included	F945S	2	SE90F		
8"		F965	1	Poly Included	F965S	2	SE90F		
<b>99-04 F-250, F-350 Super Duty 4WD with Gas Engine</b>									
2"		F920	1	Poly Included	F920S	2	SE90F		
4"		F940	1	Poly Included	F940S	2	SE90F		
6"		F960	1	Poly Included	F960S	2	SE90F		
8"		F980	1	Poly Included	F980S	2	SE90F		
<b>99-04 F-250, F-350 Super Duty 4WD with Diesel Engine</b>									
1.5"		F920	1	Poly Included	F920S	2	SE90F		
4"		F945	1	Poly Included	F945S	2	SE90F		
6"		F965	1	Poly Included	F965S	2	SE90F		
8"		F985	1	Poly Included	F985S	2	SE90F		
<b>80-98 F-250 4WD</b>									
4"		F840	1	Poly Included	F840S	2	SE80F	1	FLF840
6"		F860	1	Poly Included	F860S	2	SE80F	1	FLF860
<b>77.5-79 F-250 4WD</b>									
4"		F724	1	Poly Included	F724S	2	SE70F	1	FLF724
6"		F746	1	Poly Included	F746S	2	SE70F	1	FLF746
<b>67-77 F-250 Highboy</b>									
2"		F724	1	Poly Included	F724S	2	SE70F	1	FLF724
4"		F746	1	Poly Included	F746S	2	SE70F	1	FLF746
<b>86-98 F-350 Straight Axle 4WD</b>									
3-4"		F840	1	Poly Included	F840S	2	SE80F	1	FLF840
5-6"		F860	1	Poly Included	F860S	2	SE80F	1	FLF860
<b>80-85 F-350 4WD</b>									
4"		F840	1	Poly Included	F840S	2	SE80F	1	FLF840
6"		F860	1	Poly Included	F860S	2	SE80F	1	FLF860
<b>79 F-350 Low Boy</b>									
3-4"		F724	1	Poly Included	F724S	2	SE70F	1	FLF724
5-6"		F746	1	Poly Included	F746S	2	SE70F	1	FLF746

# FRONT SOFTRIDE® LEAF SPRINGS

FRONT LIFT	NOTES	Spring PAIRS WITH Bushings	Qty.	Bushing SETS For Spring PAIRS	SINGLE Spring	Qty.	Bushing SETS To Fit 2 Single Springs	Qty.	FITTED LEAFS For Pair
<b>JEEP</b>									
<b>87-96 Wrangler YJ</b>									
2-2.5"		YJ20F	1	Poly Included	YJ20FS	2	SE4YJ	1	FLYJ20F
3.5"-4"		YJ40F	1	Poly Included	YJ40FS	2	SE4YJ	1	FLYJ40F
<b>87-96 Wrangler YJ Rock Ready® Double Military Wrap</b>									
2.5"		YJ25F	1	Poly Included	YJ25FS	2	SE45YJ		
4"		YJ45F	1	Poly Included	YJ45FS	2	SE45YJ		
<b>76-86 CJ &amp; Scrambler</b>									
2-2.5"		J20F	1	Poly Included	J20FS	2	SE40J	1	FLJ20F
3.5"-4"		J40F	1	Poly Included	J40FS	2	SE40J	1	FLJ40F
<b>55-75 CJ</b>									
2-2.5"		J32F	1	Poly Included	J32FS	2	SE34J	1	FLJ32F
3.5"-4"		J34F	1	Poly Included	J34FS	2	SE34J	1	FLJ34F
<b>84-91 Grand Wagoneer 4WD - Full-Size</b>									
3.5-4"		JP40F	1	Poly Included	JP40FS	2	SE4JP	1	FLJP40F
<b>74-83 Cherokee, Wagoneer 4WD - Full-Size</b>									
3.5-4"		JP40F	1	Poly Included	JP40FS	2	SE4JP	1	FLJP40F
<b>74-88 J10, J20 Pickup 4WD - Full-Size</b>									
3.5-4"		JP40F	1	Poly Included	JP40FS	2	SE4JP	1	FLJP40F
<b>TOYOTA</b>									
<b>79-85 Pickup &amp; 4Runner 4WD</b>									
3"		T303	1	Poly Included	T303S	2	SE30T	1	FLT303
5"		T305	1	Poly Included	T305S	2	SE30T	1	FLT305
7"		T307	1	Poly Included	T307S	2	SE30T	1	FLT307
<b>64-80 FJ40 LandCruiser 4WD</b>									
2.5"		L20F	1	Poly Included	L20FS	2	SE40L	1	FLL20F
4"		L40F	1	Poly Included	L40FS	2	SE40L	1	FLL40F
<b>INTERNATIONAL</b>									
<b>72-82 Scout II, Terra, Traveler 4WD</b>									
2"		S20F	1	Poly Included	S20FS	2	SE40S	1	FLS20F
4"		S40F	1	Poly Included	S40FS	2	SE40S	1	FLS40F

# REAR SOFTRIDE® LEAF SPRINGS

**Softride® Technology** enhances every steely aspect of leaf spring performance, giving you all the vigorous off-road handling needed while providing the smooth street riding characteristics that you demand. Skyjacker's advanced method of shotpeening, tapered leaves, Teflon® wear pads and 'presetting' process achieves articulation at its best... without sacrificing the life of the spring. From this chart, you can find a 'Pair of Springs with Bushings' or 'Single Springs' and the 'Bushings Sets' needed for the Single unit (Ordered Separately). Also available are 'Fitted Leafs'. Fitted Leafs are designed as an option Exclusively for Skyjacker® Softride® Lifted Leaf Springs. These are used when the additional weight of aftermarket accessories are installed such as a heavy winch bumper, an engine conversion, a swing-away tire carrier, all you extra gear, etc.).

FRONT LIFT	NOTES	Spring PAIRS WITH Bushings	Qty.	Bushing SETS For Spring PAIRS	SINGLE Spring	Qty.	Bushing SETS To Fit 2 Single Springs	Qty.	FITTED LEAFS For Pair
<b>CHEVROLET/GMC</b>									
<b>99-06 1500 1/2 Ton Pickup 4WD</b>									
5"		CR55	1	Pre-Installed Rubber	CR55S	2	Pre-Installed Rubber		
<b>01-07 1500HD / 2500 Pickup 4WD</b>									
5"		CR75	1	Pre-Installed Rubber	CR75S	2	Pre-Installed Rubber		
<b>01-09 2500HD 3/4 &amp; 1 Ton Pickup 4WD</b>									
5"		CR75	1	Pre-Installed Rubber	CR75S	2	Pre-Installed Rubber		
<b>88-98 1/2, 3/4 Ton 6-Lug Pickup 4WD</b>									
5-5.5"		CR35	1	Pre-Installed Rubber	CR35S	2	Pre-Installed Rubber		FLCR35
<b>69-87 1/2, 3/4 Ton Pickup 4WD with 52" Rear Springs</b>									
2"		CR12	1	Pre-Installed Rubber	CR12S	2	Pre-Installed Rubber		FLCR12
4"		CR14	1	Pre-Installed Rubber	CR14S	2	Pre-Installed Rubber		FLCR14
6"		CR16	1	Pre-Installed Rubber	CR16S	2	Pre-Installed Rubber		FLCR16
8"		CR18	1	Pre-Installed Rubber	CR18S	2	Pre-Installed Rubber		FLCR18
<b>69-87 1/2 &amp; 3/4 Ton Pickup 4WD with 56" Rear Springs</b>									
4"		CR24	1	Pre-Installed Rubber	CR24S	2	Pre-Installed Rubber		FLCR24
6"		CR26	1	Pre-Installed Rubber	CR26S	2	Pre-Installed Rubber		FLCR26
<b>92-98 Blazer\Tahoe, Jimmy\Yukon 4WD</b>									
2"		CR12	1	Pre-Installed Rubber	CR12S	2	Pre-Installed Rubber		FLCR12
4"		CR14	1	Pre-Installed Rubber	CR14S	2	Pre-Installed Rubber		FLCR14
6"		CR16	1	Pre-Installed Rubber	CR16S	2	Pre-Installed Rubber		FLCR16
8"		CR18	1	Pre-Installed Rubber	CR18S	2	Pre-Installed Rubber		FLCR18
<b>73-91 Blazer, Jimmy 4WD</b>									
2"		CR12	1	Pre-Installed Rubber	CR12S	2	Pre-Installed Rubber		FLCR12
4"		CR14	1	Pre-Installed Rubber	CR14S	2	Pre-Installed Rubber		FLCR14
6"		CR16	1	Pre-Installed Rubber	CR16S	2	Pre-Installed Rubber		FLCR16
8"		CR18	1	Pre-Installed Rubber	CR18S	2	Pre-Installed Rubber		FLCR18
<b>69-72 Blazer, Jimmy 4WD</b>									
2"		CR14	1	Pre-Installed Rubber	CR14S	2	Pre-Installed Rubber		FLCR14
4"		CR16	1	Pre-Installed Rubber	CR16S	2	Pre-Installed Rubber		FLCR16
6"		CR18	1	Pre-Installed Rubber	CR18S	2	Pre-Installed Rubber		FLCR18
<b>92-99 Suburban 1/2, 3/4 Ton 6-Lug &amp; 8-Lug 4WD</b>									
2"		CR32	1	Pre-Installed Rubber	CR32S	2	Pre-Installed Rubber		FLCR32
<b>69-91 Suburban 4WD with 52" Rear Springs</b>									
2"		CR14	1	Pre-Installed Rubber	CR14S	2	Pre-Installed Rubber		FLCR14
4"		CR16	1	Pre-Installed Rubber	CR16S	2	Pre-Installed Rubber		FLCR16
6"		CR18	1	Pre-Installed Rubber	CR18S	2	Pre-Installed Rubber		FLCR18
<b>69-91 Suburban 4WD with 56" Rear Springs</b>									
4"		CR24	1	Pre-Installed Rubber	CR24S	2	Pre-Installed Rubber		FLCR24
6"		CR26	1	Pre-Installed Rubber	CR26S	2	Pre-Installed Rubber		FLCR26
<b>DODGE</b>									
<b>02-06 1/2 Ton Ram Pickup 4WD</b>									
5"		DR250	1	Pre-Installed Rubber	DR250S	2	Pre-Installed Rubber		
<b>94-01 1/2 &amp; 3/4 Ton Ram Pickup 4WD with 2.5" Wide Rear Springs</b>									
2"	Q7	DR56	1	Pre-Installed Rubber	DR56S	2	Pre-Installed Rubber		
4"		DR54	1	Pre-Installed Rubber	DR54S	2	Pre-Installed Rubber		FLDR54

# REAR SOFTRIDE® LEAF SPRINGS

FRONT LIFT	NOTES	Spring PAIRS WITH Bushings	Qty.	Bushing SETS For Spring PAIRS	SINGLE Spring	Qty.	Bushing SETS To Fit 2 Single Springs	Qty.	FITTED LEAFS For Pair
<b>DODGE - Continued</b>									
<b>94-01 1/2 &amp; 3/4 Ton Ram Pickup 4WD with 2.5" Wide Rear Springs</b>									
6"		DR56	1	Pre-Installed Rubber	DR56S	2	Pre-Installed Rubber		
KIT NOTES: Q7. The Factory Block is Removed.									
<b>03-06 3/4 Ton Ram Pickup 4WD</b>									
4"		DR374	1	Pre-Installed Rubber	DR374S	2	Pre-Installed Rubber		
<b>94-01 3/4 Ton Heavy Duty &amp; 1 Ton Ram Pickup 4WD with 3" Wide Rear Springs</b>									
1-1.5"	Q7	DR76	1	Pre-Installed Rubber	DR76S	2	Pre-Installed Rubber		FLDR76
4"		DR74	1	Pre-Installed Rubber	DR74S	2	Pre-Installed Rubber		FLDR74
6"		DR76	1	Pre-Installed Rubber	DR76S	2	Pre-Installed Rubber		FLDR76
KIT NOTES: Q7. The Factory Block is Removed.									
<b>72-93 1/2 &amp; 3/4 Ton Pickup 4WD</b>									
4"	Q6	DR40	1	Pre-Installed Rubber	DR40S	2	Pre-Installed Rubber		FLDR40
6"	Q6	DR60	1	Pre-Installed Rubber	DR60S	2	Pre-Installed Rubber		FLDR60
KIT NOTES: Q6. Factory Block Can Be Removed to Reduce Lift 3.5" (Cummins Models will be 4-6" Less Lift). Some 3/4 & 1 Ton Models have 3/4" Spring Eye Bolts and REQUIRE Bushing Kit # SE17D.									
<b>72-93 Ramcharger, Trailduster 4WD</b>									
6"	Q6	DR40	1	Pre-Installed Rubber	DR40S	2	Pre-Installed Rubber		FLDR40
8"	Q6	DR60	1	Pre-Installed Rubber	DR60S	2	Pre-Installed Rubber		FLDR60
KIT NOTES: Q6. Factory Block Can Be Removed to Reduce Lift 3.5" (Cummins Models will be 4-6" Less Lift). Some 3/4 & 1 Ton Models have 3/4" Spring Eye Bolts and REQUIRE Bushing Kit # SE17D.									
<b>FORD</b>									
<b>2009 F-150 4WD</b>									
4"		FR904	1	Pre-Installed Rubber	FR904S	2	Pre-Installed Rubber		
<b>04-08 F-150 4WD</b>									
4.5"		FR44	1	Pre-Installed Rubber	FR44S	2	Pre-Installed Rubber		FLFR44
<b>97-03 F-150 4WD Includes SuperCrew</b>									
5"		FR15	1	Pre-Installed Rubber	FR15S	2	Pre-Installed Rubber		
<b>73-96 F-100, F-150 4WD</b>									
2"		FR52	1	Pre-Installed Rubber	FR52S	2	Pre-Installed Rubber		FLFR52
4"	Q1	FR54	1	Pre-Installed Rubber	FR54S	2	Pre-Installed Rubber		FLFR54
6-8"	Q1	FR56	1	Pre-Installed Rubber	FR56S	2	Pre-Installed Rubber		FLFR56
KIT NOTES: Q1. Factory Block Can Be Removed on 4WD to Reduce Lift 2" on 80-86 Models or 3.25" on 73-79 Models.									
<b>80-96 F-100, F-150 2WD</b>									
2"		FR34	1	Pre-Installed Rubber	FR34S	2	Pre-Installed Rubber		
4"		FR36	1	Pre-Installed Rubber	FR36S	2	Pre-Installed Rubber		
<b>78-96 Bronco 4WD</b>									
2"		FR51	1	Pre-Installed Rubber	FR51S	2	Pre-Installed Rubber		FLFR51
4"		FR52	1	Pre-Installed Rubber	FR52S	2	Pre-Installed Rubber		FLFR52
6"		FR54	1	Pre-Installed Rubber	FR54S	2	Pre-Installed Rubber		FLFR54
8"		FR56	1	Pre-Installed Rubber	FR56S	2	Pre-Installed Rubber		FLFR56
<b>66-77 Bronco 4WD</b>									
4.5"		FR64	1	Pre-Installed Rubber	FR64S	2	Pre-Installed Rubber		FLFR64
<b>00-04 Excursion 4WD</b>									
4"		FR94	1	Pre-Installed Rubber	FR94S	2	Pre-Installed Rubber		
6"		FR96	1	Pre-Installed Rubber	FR96S	2	Pre-Installed Rubber		
8"		FR98	1	Pre-Installed Rubber	FR98S	2	Pre-Installed Rubber		
<b>80-98 F-250 4WD, 2WD</b>									
1-2"		FR52	1	Pre-Installed Rubber	FR52S	2	Pre-Installed Rubber		FLFR52
3-4"	Q1	FR54	1	Pre-Installed Rubber	FR54S	2	Pre-Installed Rubber		FLFR54
5-6"	Q1	FR56	1	Pre-Installed Rubber	FR56S	2	Pre-Installed Rubber		FLFR56
KIT NOTES: Q1. Factory Block Can Be Removed on 4WD to Reduce Lift 2" on 80-86 Models or 3.25" on 73-79 Models.									
<b>77.5-79 F-250 Lowboy 4WD</b>									
1-2"		FR52	1	Pre-Installed Rubber	FR52S	2	Pre-Installed Rubber		FLFR52
3-4"	Q3	FR54	1	Pre-Installed Rubber	FR54S	2	Pre-Installed Rubber		FLFR54
5-6"	Q3	FR56	1	Pre-Installed Rubber	FR56S	2	Pre-Installed Rubber		FLFR56
KIT NOTES: Q3. Factory Block Can Be Removed to Reduce Lift 3.25".									

# REAR SOFTRIDE® LEAF SPRINGS

FRONT LIFT	NOTES	Spring PAIRS WITH Bushings	Qty.	Bushing SETS For Spring PAIRS	SINGLE Spring	Qty.	Bushing SETS To Fit 2 Single Springs	Qty.	FITTED LEAFS For Pair
<b>FORD - Continued</b>									
<b>08-09 F-250/F-350 Super Duty 4WD</b>									
4"		FR84	1	Pre-Installed Rubber	FR84S	2	Pre-Installed Rubber		
6"		FR86	1	Pre-Installed Rubber	FR86S	2	Pre-Installed Rubber		
8"		FR88	1	Pre-Installed Rubber	FR88S	2	Pre-Installed Rubber		
<b>99-07 F-250/F-350 Super Duty 4WD</b>									
4"		FR94	1	Pre-Installed Rubber	FR94S	2	Pre-Installed Rubber		
6"		FR96	1	Pre-Installed Rubber	FR96S	2	Pre-Installed Rubber		
8"		FR98	1	Pre-Installed Rubber	FR98S	2	Pre-Installed Rubber		
<b>66-77 F-250 Highboy 4WD</b>									
4"		FR74		Pre-Installed Rubber	FR74S	2	Pre-Installed Rubber		FLFR74
<b>79-98 F-350 4WD</b>									
1"		FR52	1	Pre-Installed Rubber	FR52S	2	Pre-Installed Rubber		FLFR52
3"		FR54	1	Pre-Installed Rubber	FR54S	2	Pre-Installed Rubber		FLFR54
5"		FR56	1	Pre-Installed Rubber	FR56S	2	Pre-Installed Rubber		FLFR56
<b>83-97 Ranger 4WD, 2WD</b>									
4"	Q2	FR34	1	Pre-Installed Rubber	FR34S	2	Pre-Installed Rubber		FLFR34
6"	Q2	FR36	1	Pre-Installed Rubber	FR36S	2	Pre-Installed Rubber		FLFR36
KIT NOTES: Q2. Factory Block Can Be Removed to Reduce Lift 2-3" Depending on Factory Block Size.									
<b>83-90 Bronco II 4WD, 2WD</b>									
4"		FR34	1	Pre-Installed Rubber	FR34S	2	Pre-Installed Rubber		FLFR34
6"		FR36	1	Pre-Installed Rubber	FR36S	2	Pre-Installed Rubber		FLFR36
<b>JEEP</b>									
<b>87-96 Wrangler YJ</b>									
2-2.5"		YJ20R	1	Poly Included	YJ20RS	2	SE4YJ	1	FLYJ20R
3.5"-4"		YJ40R	1	Poly Included	YJ40RS	2	SE4YJ	1	FLYJ40R
<b>87-96 Wrangler YJ Rock Ready® Double Military Wrap</b>									
2.5"		YJ25R	1	Poly Included	YJ25RS	2	SE45YJ	1	
4"		YJ45R	1	Poly Included	YJ45RS	2	SE45YJ	1	
<b>76-86 CJs &amp; Scrambler</b>									
2-2.5"		J20R	1	Poly Included	J20RS	2	SE45J	1	FLJ20R
3.5"-4"		J40R	1	Poly Included	J40RS	2	SE45J	1	FLJ40R
<b>55-75 CJs</b>									
2-2.5"		J32R	1	Poly Included	J32RS	2	SE34J	1	FLJ32R
3.5"-4"		J34R	1	Poly Included	J34RS	2	SE34J	1	FLJ34R
<b>84-01 Cherokee XJ 4WD, 2WD</b>									
2.5"		JC25R	1	Pre-Installed Rubber	JC25RS	2	Pre-Installed Rubber		FLJC25R
5.5"	Q5	JC55R	1	Pre-Installed Rubber	JC55RS	2	Pre-Installed Rubber		
7.5"	Q5	JC75R	1	Pre-Installed Rubber	JC75RS	2	Pre-Installed Rubber		
KIT NOTES: Q5. Skyjacker Shackles # SH130 Are REQUIRED and included.									
<b>84-91 Grand Wagoneer 4WD - Full-Size</b>									
3-4"		JP40R	1	Pre-Installed Rubber	JP40RS	2	Pre-Installed Rubber		FLJP40R
<b>76-83 Cherokee, Wagoneer 4WD - Full-Size</b>									
4"		JP40R		Pre-Installed Rubber	JP40RS	2	Pre-Installed Rubber		FLJP40R
<b>74-88 J10, J20 Pickup 4WD - Full-Size</b>									
4"	Q8	JP40R	1	Pre-Installed Rubber	JP40RS	2	Pre-Installed Rubber		FLJP40R
KIT NOTES: Q8. 74-75 Models MUST Have 131" Wheel Base & 7,200 lb. GVWR or more for Rear Springs to Fit.									
<b>TOYOTA</b>									
<b>07-09 Tundra 4WD</b>									
4-4.5"		TUR74		Pre-Installed Rubber	TUR74S	2	Pre-Installed Rubber		
<b>05-06 Tacoma 4WD</b>									
1.5"-2"		TCR515		Pre-Installed Rubber	TCR515S	2	Pre-Installed Rubber		
<b>98-04 Tacoma 4WD, 2WD</b>									
2.5"		TCR25	1	Pre-Installed Rubber	TCR25S	2	Pre-Installed Rubber		
<b>95-97 Tacoma 4WD, 2WD</b>									
3.5"		TR39	1	Poly Included	TR39S	2	SE39T	1	FLTR39

# REAR SOFTRIDE® LEAF SPRINGS

FRONT LIFT	NOTES	Spring PAIRS WITH Bushings	Qty.	Bushings SETS For Spring PAIRS	SINGLE Spring	Qty.	Bushings SETS To Fit 2 Single Springs	Qty.	FITTED LEAFS For Pair
<b>TOYOTA - Continued</b>									
<b>89-95 Pickup 4WD</b>									
4"		TR49	1	Poly Included	TR49S	2	SE39T	1	FLTR49
<b>79-88 Pickup 4WD</b>									
2"		TR20	1	Poly Included	TR20S	2	SE35T	1	FLTR20
4"		TR40	1	Poly Included	TR40S	2	SE35T	1	FLTR40
6"		TR60	1	Poly Included	TR60S	2	SE35T	1	FLTR60
<b>85-89 4Runner 4WD</b>									
0-1"		TR20	1	Poly Included	TR20S	2	SE35T	1	FLTR20
<b>85-89 4Runner 4WD</b>									
2-3"		TR40	1	Poly Included	TR40S	2	SE35T	1	FLTR40
4-5"		TR60	1	Poly Included	TR60S	2	SE35T	1	FLTR60
<b>64-80 FJ40 LandCruiser 4WD</b>									
2.5"		L20R	1	Poly Included	L20RS	2	SE40L	1	FLL20R
3.5"		L40R	1	Poly Included	L40RS	2	SE40L	1	FLL40R
<b>INTERNATIONAL</b>									
<b>72-82 Scout II, Terra, Traveler 4WD</b>									
2"		S20R	1	Poly Included	S20RS	2	SE40S	1	FLS20R
4"		S40R	1	Poly Included	S40RS	2	SE40S	1	FLS40R



<b>LEAF SPRING ACCESSORIES</b>		
<b>Replacement Teflon® Wear Pads - Pair</b>		
<b>- Fits LEAF SPRING MODELS with 2", 2.5 or 3" Wide Leaf Springs.</b>		
Spring Width	Button Style	Part #
2"	Single	IN200C
2.5"	Single	IN212C
2.5"	Double	IN212D
2.5"	Off-Center	IN212O
3"	Single	IN300C
3"	Double	IN300D