

Required Tools List:

- SAE Sockets \ Wrenches
- Metric Sockets \ Wrenches
- Diagonal Cutting Pliers
- Safety Glasses
- Wheel Chock
- Torque Wrench



Before beginning the installation, read these instructions thoroughly & completely. Please refer to the Parts List to insure that all parts & hardware are received prior to disassembly of the vehicle. If any parts are found to be missing, contact SKYJACKER® Customer Service at 318-388-0816 to obtain the needed items. If you have any questions or reservations about installing this product, contact SKYJACKER® Technical Assistance at 318-388-0816.

Component Box Breakdown:

Part # 7014

Item #	Description	Qty
7000WS	STEERING DAMPER, WHITE	1
B10RS	BOOT STABILIZER, RED	1
BTIE	BOOT CABLE TIE, RED	1
HYDRO 6X2-CL	DECAL, HYDRO STABILIZER	1
HB-7014	HDWR BAG: 7014 / 9014	1

Part # 8014

Item #	Description	Qty
8000BS	STEERING DAMPER, BLACK	1
B10KS	BOOT STABILIZER, BLACK	1
BTIE-K	BOOT CABLE TIE, BLACK	1
MXSD	DECAL, BLACK MAX STABILIZER	1
HB-8014	HDWR BAG: 8014	1

Part # 9014

Item #	Description	Qty
9000WS	STEERING DAMPER, SILVER	1
B10KS	BOOT STABILIZER, BLACK	1
BTIE-K	BOOT CABLE TIE, BLACK	1
SSD	DECAL, SILVER STABILIZER	1
HB-7014	HDWR BAG: 7014 / 9014	1

Hardware Bag Breakdown:

Part # HB-7014

Item #	Description	Qty
HOURGLASS 5/8	HOURGLASS, 5/8 X 1.50, RED	1
HG58125	HOURGLASS, 5/8 X 1.25, RED	1
141509	ES25 SLEEVE, 1.50 LONG	1
142121	ES24 SLEEVE, 1.38 LONG	1

Part # HB-8014

Item #	Description	Qty
HG5815-K	HOURGLASS, 5/8 X 1.50, BLACK	1
HG58125-K	HOURGLASS, 5/8 X 1.25, BLACK	1
141509	ES25 SLEEVE, 1.50 LONG	1
142121	ES24 SLEEVE, 1.38 LONG	1

Pre-Installation Tips: Install Stabilizer Boot, Bushings and Sleeves.

1. Install supplied Stabilizer Boot over Skyjacker Steering Stabilizer. Attach boot to cylinder body with supplied Boot Cable Tie. Remove excess cable tie with diagonal cutting pliers.

2. Coat 1.50" Hourglass Bushings with a water resistant grease & press into stabilizer shaft eye.
Coat 1.50" Steel Sleeve with a water resistant grease & press into shaft eye bushing.
Coat 1.25" Hourglass Bushings with a water resistant grease & press into stabilizer cylinder body eye.
Coat 1.25" Steel Sleeve with a water resistant grease & press into cylinder body eye bushing.

Installation: **Note:** Save all factory components & hardware for reuse, unless noted.

1. Chock rear tires\wheels. Ensure that vehicle transmission is in PARK and engage emergency brake. **Note:** Be sure steering wheel\wheels are pointing straight forward.
2. Remove OEM steering stabilizer from front center link axle bracket & from passenger side axle bracket mount.
3. Install Skyjacker steering stabilizer shaft end to passenger side OEM axle bracket with OEM hardware. (Photo # 1)
4. Install Skyjacker steering stabilizer cylinder body end to OEM front center link axle bracket with OEM hardware. (Photo # 2)
5. Tighten at passenger side OEM axle bracket. Torque 56 ft-lb.
Tighten front center link axle bracket. Torque 65 ft-lb.
6. After installation be sure to cycle steering & check for adequate clearance.



Final Notes:

- After installation is complete, double check that all nuts & bolts are tight.
- With vehicle placed on ground, cycle steering lock to lock & inspect steering for proper operation, tightness & adequate clearance.
- After first 100 miles, check all hardware for proper torque & periodically thereafter.

Seat Belts Save Lives. Please Wear Your Seat Belt.