

www.skyjacker.com

REQUIRED TOOL LIST:

- Safety Glasses
- Metric / Standard Sockets & Wrenches
- Floor Jack
- Jack Stands
- Measuring Tape
- Torque Wrench



Jeep Wrangler JK 4WD 2"- 2.5" Lowering Kit Installation Instructions

Before beginning the installation, thoroughly & completely read these instructions & the enclosed driver's WARNING NOTICE. Affix the WARNING decal in the passenger compartment in clear view of all occupants. Please refer to the Parts List to insure that all parts & hardware are received prior to the disassembly of the vehicle. If any parts are found to be missing, contact SKYJACKER[®] Customer Service at 318-388-0816 to obtain the needed items. If you have any questions or reservations about installing this lift kit, call SKYJACKER[®] Technical Assistance at 318-388-0816.

Make sure you park the vehicle on a level concrete or asphalt surface. Many times a vehicle is not level (side-to-side) from the factory & is usually not noticed until a lowering kit has been installed, which makes the difference more visible. Using a measuring tape, measure the front & rear (both sides) from the ground up to the center of the fender opening above the axle. Record this information below for future reference.

Driver Side Front:	Passenger Side Front:
Driver Side Rear:	Passenger Side Rear:

IMPORTANT NOTES:

• After installation, a qualified alignment facility is required to align the vehicle to OEM specifications.

Kit Box Breakdown:

Part #: LOWJK024

ITEM#	DESCRIPTION	QTY	
JK015FS4X4	LOWJACKER JK 4X4 FRONT COIL	2	
JK025RS4X4	LOWJACKER JK 4X4 REAR COIL	2	
WD1	WARNING DECAL	1	
I-LOWJK	INST SHEET: LOWJK024	1	

I-LOWJK REV2 7-20 Pg 1

Front Installation:

- 1. Park the vehicle on flat, level ground, set the emergency brake, & block the rear tires / wheels.
- 2. Raise the front of the vehicle & support the frame rails & differential using jack stands.
- 3. Remove the front tires / wheels & disconnect the front sway bar end links using a 18mm socket.
- 4. Disconnect the front track bar using a 21mm socket. (See Photo # 1)
- 5. Disconnect the front shocks using a 18mm socket.
- 6. Lower the differential & remove the front coil springs. (See Photo # 2)
- 7. Install the new Skyjacker front coil springs & let the weight of the frame down on to the new coil springs.
- 8. Reconnect the front sway bar end links, front track bar, & install the new Skyjacker front shocks using the supplied & OEM hardware. (See Photo # 3)
- 9. Install the front tires / wheels & lower the vehicle to the ground.

Rear Installation:

- 1. Block the front tires / wheels.
- 2. Raise the rear of the vehicle & support the frame rails & differential using jack stands.
- 3. Remove the rear tires / wheels & disconnect the rear sway bar end links using a 18mm socket.
- 4. Disconnect the rear track bar using a 21mm socket. (See Photo # 4)
- 5. Disconnect the rear shocks using a 16mm socket & disconnect the ABS line & brake line from the frame. (See Photo # 5)
- 6. Lower the differential & remove the rear coil springs.











I-LOWJK

- 7. Install the new Skyjacker rear coil springs & let the weight of the frame down on to the new coil springs. (See Photo # 6)
- 8. Reconnect the rear sway bar end links, rear track bar, & install the new Skyjacker rear shocks using the supplied & OEM hardware. (See Photo #7)
- 9. Install the rear tires / wheels & lower the vehicle to the ground.

FINAL NOTES:

- After the installation is complete, double check that all nuts & bolts are tight. Refer to the following chart below for the proper torque specifications. (Do not retighten the nuts & bolts where thread lock compound was used.)
- With the vehicle placed on the ground, cycle the steering lock to lock & inspect the steering, suspension, brake lines, front & rear drivelines, fuel lines, & wiring harnesses for proper operation, tightness, & adequate clearance.
- Have the headlights readjusted to the proper settings.
- Have a qualified alignment center realign the vehicle to the OEM specifications.
- Retorque all the bolts after the first 100 miles.





TORQUE SPECIFICATIONS							
	INCH SYSTEM			METRIC SYSTEM			
Bolt Size	Grade 5	Grade 8	Bolt Size	Class 8.8	Class 10.9		
<u>5/16</u>	15 FT LB	20 FT LB	6MM	5 FT LB	9 FT LB		
3/8	30 FT LB	35 FT LB	8MM	18 FT LB	23 FT LB		
7/16	45 FT LB	60 FT LB	10MM	32 FT LB	45 FT LB		
1/2	65 FT LB	90 FT LB	12MM	55 FT LB	75 FT LB		
9/16	95 FT LB	130 FTLB	14MM	85 FT LB	120 FT LB		
5/8	135 FT LB	175 FT LB	<u>16MM</u>	130 FT LB	165 FT LB		
3/4	185 FT LB	280 FT LB	18MM	170 FT LB	240 FT LB		

[•] The above specifications are not to be used when the bolt is being installed with a bushing.

Seat Belts Save Lives, Please Wear Your Seat Belt.

I-LOWJK Pg 3





Jesus Christ Died For You.

John 3:16

For God so loved the world that He gave His only Son, so that everyone who believes in Him should not perish, but have everlasting life.

For all have sinned; all fall short of God's glorious standard. Ephesians 2:8

God saved you by his special favor when you believed. And you can't take credit for this; it is a gift from God.

The Lord is my Rock, my fortress, and my savior; my God is my Rock, in whom I find protection. He is my shield, the strength of my salvation, and my stronghold.

That if you shall confess with thy mouth the Lord Jesus, and shall believe in your heart that God hath raised him from the dead, you shall be saved. For with the heart man believeth unto righteousness; and with the mouth confession is made unto salvation.

Pray This Simple Prayer:

God, I come to You admitting I have sinned against You and I need you to take control of my life. The Bible says anyone who calls on the name of the Lord will be saved. I am calling on You, Jesus. I ask that You come live in my heart and be the Lord over my life today. I do believe You died on the cross for me and came back to life to give me life! Thank You, Lord Jesus for a new life in You!

Now, go and tell somebody about your new life in Jesus, get a Bible, begin to read it, and go to a Bible believing church.

If you would like someone to pray with you, call Kenneth Copeland Ministries anytime at 800-600-7395.

To listen to commercial free Christian radio on the web, go to www.887fm.org

Jesús murió por ti.

Juan 3:16

"Porque tanto amó Dios al mundo, que dio a su Hijo unigénito, para que todo el que cree en él no se pierda, sino que tenga vida eterna."

"Pues todos han pecado y están privados de la gloria de Dios."
Efesios 2:8

"Porque por gracia ustedes han sido salvados mediante la fe; esto no procede de ustedes, sino que es el regalo de Dios." Salmos 18:2

"El Señor es mi roca, mi amparo, mi libertador; es mi Dios, el peñasco en que me refugio. Es mi escudo, el poder que me salva, ¡mi más alto escondite!"

Romanos 10:9-10

"9 Que si confi esas con tu boca que Jesús es el Señor, y crees en tu corazón que Dios lo levantó de entre los muertos, serás salvo. 10 Porque con el corazón se cree para ser justifi cado, pero con la boca se confi esa para ser salvo."

Ahora dí esta simple oración:

Dios, vengo a Ti y admito que he pecado contra Ti, necesito que tomes el control de mi vida. La Biblia dice que todo aquel que invoca el nombre del Señor escapará con vida. En este momento yo clamo ante Ti, Jesús; te pido que vengas a vivir en mi corazón y que tomes el control de mi vida. ¡Yo creo que tu moriste en la cruz y resucitaste para darme vida! ¡Gracias Señor Jesús, por una nueva vida que tengo en Ti! Amen.

Ahora ve y dile a alguien sobre la nueva vida que tienes en Cristo. Compra una Biblia y empieza a leerla. Busca una Iglesia que cree en la Biblia y hazte parte de esa Iglesia.

Si te gustaría orar con alguien, puedes llamar a este número 800-600-7395

Puedes ir a este sitio de Internet para escuchar música Cristiana sin anuncios, www.887fm.org

