



www.skyjacker.com

Jeep Wrangler JK Double Disconnect Sway Bar End Links Installation Instructions

REQUIRED TOOL LIST:

- Safety Glasses
- Metric / Standard Wrenches & Sockets
- Torque Wrench

Before beginning the installation, thoroughly & completely read these instructions. If any parts are found to be missing, contact SKYJACKER® Customer Service at 318-388-0816 to obtain the needed items. If you have any questions or reservations about installing this product, contact SKYJACKER® Technical Assistance at 318-388-0816.

Installation:

1. With the vehicle on flat level ground, set the emergency brake & block the rear tires / wheels.
2. Remove the OEM sway bar end links from the OEM sway bar & axle brackets.
3. Apply lithium grease to the supplied metal sleeves & insert the metal sleeves into the new Skyjacker end link eyes.
4. Assemble the new Skyjacker end links using the supplied 1/4" snap pins.
5. Install the new Skyjacker end links to the OEM axle brackets using the OEM hardware. (See Photo # 1)
6. Install the new Skyjacker end links to the OEM sway bar using the supplied 1/2" x 2 1/2" bolts, washers, & nuts. (See Photo # 1)



Photo # 1

Final Notes:

- After the installation is complete, double check that all nuts & bolts are tight. Refer to the following chart for the proper torque specifications. (Do not retighten the nuts & bolts where thread lock compound was used.)
- With the vehicle placed on the ground, cycle the steering lock to lock & inspect the steering, suspension, brake lines, front & rear drivelines, fuel lines, & wiring harnesses for proper operation, tightness, & adequate clearance.

- After the first 100 miles, check all hardware for the proper torque & periodically thereafter.

TORQUE SPECIFICATIONS					
<u>INCH SYSTEM</u>			<u>METRIC SYSTEM</u>		
Bolt Size	Grade 5	Grade 8	Bolt Size	Class 8.8	Class 10.9
5/16	15 FT LB	20 FT LB	6MM	5 FT LB	9 FT LB
3/8	30 FT LB	35 FT LB	8MM	18 FT LB	23 FT LB
7/16	45 FT LB	60 FT LB	10MM	32 FT LB	45 FT LB
1/2	65 FT LB	90 FT LB	12MM	55 FT LB	75 FT LB
9/16	95 FT LB	130 FT LB	14MM	85 FT LB	120 FT LB
5/8	135 FT LB	175 FT LB	16MM	130 FT LB	165 FT LB
3/4	185 FT LB	280 FT LB	18MM	170 FT LB	240 FT LB

- The above specifications are not to be used when the bolt is being installed with a bushing.

Seat Belts Save Lives, Please Wear Your Seat Belt.