



www.skyjacker.com

REQUIRED TOOL LIST:

- Safety Glasses
- Metric / Standard Wrenches & Sockets
- Measuring Tape
- Torque Wrench

Jeep Wrangler JK 2"- 5" Single Flex Lower Links Installation Instructions



Before beginning the installation, thoroughly & completely read these instructions. Please refer to the Parts List to insure that all parts & hardware are received prior to the disassembly of the vehicle. If any parts are found to be missing, contact SKYJACKER® Customer Service at 318-388-0816 to obtain the needed items. If you have any questions or reservations about installing this product, contact SKYJACKER® Technical Assistance at 318-388-0816.

Important Notes:

- After installation, a qualified alignment facility is required to align the vehicle to the OEM specifications.

Component Box Breakdown:

Part #: JK24LLX

Item #	Description	Qty	Item #	Description	Qty
JKLL24F-SX-L	JK FRONT LOWER LK SGL FLEX	2	114RFTJN	JAM NUT / 1.25 RH THREAD	4
DLL23-SX-L	JK REAR LOWER LK SGL FLEX	2	I-JK24LLX	INST SHEET: JK24LLX	1
RE114-916R	ROD END / 1.25 RH THD / .562 ID	4			

Installation:

1. Park the vehicle on a flat level surface, set the emergency brake, & block the front & rear tires / wheels.
2. Measure the length of the new Skyjacker lower control arms between the center of the rod end & bushing on each control arm. Rotate the rod end as needed, being sure to keep the ends square with each other until the new Skyjacker front lower control arms measure 22 13/16" center to center & the new Skyjacker rear lower control arms measure 20" center to center.

3. One at a time, remove the OEM lower control arms & install the new Skyjacker lower control arms using the OEM hardware. (See Photos # 1 & # 2) **Note:** Install the new front lower control arms with the offset bend toward the inside of the vehicle. Tighten each jam nut to seat against the base of the new lower control arms.

Final Notes:

- After the installation is complete, double check that all hardware is tight. Refer to the following chart for the proper torque specifications. (Do not retighten the nuts & bolts where thread lock compound was used.)
- After the first 100 miles, check all hardware for the proper torque & periodically thereafter.



TORQUE SPECIFICATIONS					
<u>INCH SYSTEM</u>			<u>METRIC SYSTEM</u>		
Bolt Size	Grade 5	Grade 8	Bolt Size	Class 8.8	Class 10.9
5/16	15 FT LB	20 FT LB	6MM	5 FT LB	9 FT LB
3/8	30 FT LB	35 FT LB	8MM	18 FT LB	23 FT LB
7/16	45 FT LB	60 FT LB	10MM	32 FT LB	45 FT LB
1/2	65 FT LB	90 FT LB	12MM	55 FT LB	75 FT LB
9/16	95 FT LB	130 FT LB	14MM	85 FT LB	120 FT LB
5/8	135 FT LB	175 FT LB	16MM	130 FT LB	165 FT LB
3/4	185 FT LB	280 FT LB	18MM	170 FT LB	240 FT LB

• The above specifications are not to be used when the bolt is being installed with a bushing.

Seat Belts Save Lives, Please Wear Your Seat Belt.